

SF20, SF30, SF35 software update

Before software update check hardware version of your measure device.

For SF 35 check HW version LCD003 or LCD004 !

1. Connect your device to PC with supplied cable
2. Start SUpdate in PC
3. Set COM port in PC
4. Select firmware in SUpdate
5. Press START in SUpdate
6. Press and hold ON button on SF 20, 30, 35 until red LED goes OFF
7. Press „TRANSFER SOFTWARE“ in SUpdate
8. Press DOWN arrow on device (SF)
9. Wait for finish update
10. Switch ON device and hold F1 button to complete erase to factory setting