

1. SATA, e-SATA , USB HDD support of AB IPBox 9xxxHD series

You can check compatibility of some HDD when connecting via **SATA** or **e-SATA** interface in table below. There are mentioned only models that were physically tested in the table. If there is a concrete model (e.g. **WD5000AACS**) mentioned it means that whole model line is also compatible (e.g. **WDxxxxAACS**). Some HDDs use SSC function – receiver may not identify it. In such a case use connection of your HDD through external USB box. AB IPBox receivers do not support simultaneous operation of two hard discs (internal and external but if you use internal HDD you can also use your USB flash memory to playback MP3 or JPEG files.

It is necessary to format your HDD after first turning on with installed HDD.

HDD producer	HDD model	capacity/GB	Size "	connection	9000HD	910HD	900HD
Western Digital	WD2500BEVS-22UST0	250	2,5	SATA 1	doesn't detect	doesn't detect	doesn't detect
Western Digital	WD5000BEVS-22ZAT0	500	2,5	SATA 1	doesn't detect	doesn't detect	doesn't detect
Western Digital	WD2500BEVS-00VAT0	250	2,5	SATA 1	doesn't detect	doesn't detect	doesn't detect
Fujitsu	MHW2120BH	120	2,5	SATA 1	OK	OK	OK
Hitachi	HTS545050KTA300	500	2,5	SATA 1	OK	OK	OK
Seagate	ST3250310NS	250	3,5	SATA 1	OK	OK	OK
Seagate	ST3500310NS	500	3,5	SATA 1	OK	OK	OK
Western Digital	WD1600AAJS	160	3,5	SATA 1	OK	OK	OK
Western Digital	WD2500AAJS	250	3,5	SATA 1	OK	OK	OK
Western Digital	WD3200AAJS	320	3,5	SATA 1	OK	OK	OK
Western Digital	WD5000AACS	500	3,5	SATA 1	OK	OK	OK
Patriot	PE128GS25SSDR	128 SSD	2,5	SATA 1	OK	OK	OK

There is "HDD check during start" item in Menu – Advanced setting – HDD setting turned into **no** to quicken the start. If a problem with records occurs try to turn it into **yes** and restart your receiver. HDD checking performs automatically. If a problem persists try to format your HDD.