

## How to set AB IPBox Universal RCU

Only the RCU of AB IPBox 350Prime, AB IPBox 900HD and AB IPBox 9000HD can be compatible with the other DGstation models.

If you press "OK" and one of the below buttons of RCU for about 10 sec. at the same time, "STB" button of RCU will blink for setting completion.

The RCU of AB IPBox 350Prime works as below

OK+1 : AB IPBox 4xxS and AB IPBox 250S

OK+3 : AB IPBox 350Prime

OK+4 : AB IPBox 200S

The RCU of AB IPBox 9000HD and AB IPBox 900HD works as below

OK+1 : AB IPBox 4xxS and AB IPBox 250S

OK+2 : AB IPBox 9000HD

OK+3 : AB IPBox 350Prime

OK+4 : AB IPBox 200S

OK+5 : AB IPBox 900HD

